

## MCS7840/7820 User Manual for Windows Vista Certified driver

---

### Installation Steps for Windows Vista 32-bit and Vista 64-bit

Following document contains the procedure for installing the MCS7840 / 7820 driver on Windows Vista 32-bit & 64-bit Operating Systems.

When you plug-in MCS-7840/7820 you get the following screen:




Click on **“Locate and Install driver software (recommended)”**.


You will get a **“User Account Control”** window saying **“An unidentified program wants access to your computer”**. Click on Allow to continue installing the Driver.

Windows will try to install driver. You can see this at the system tray, as shown in the below picture.

## MCS7840/7820 User Manual for Windows Vista Certified driver



As the drivers are not preinstalled, you will be prompted for the driver location, as shown in the below picture.



Select **“Browse my computer for driver software (advanced)”** and click on it.

In the next step, browse and provide the path manually where the driver is located.


## MCS7840/7820 User Manual for Windows Vista Certified driver

---

You will get a screen as shown below after installing MCS7840 device.




Now, Windows will try to install the serial ports of MCS7840 and prompt for it as shown below:



Select **"I don't have the disc. Show me other options"** and in the next step select **"Browse my computer for driver software (advanced)"** and click on it. Your serial ports will get installed automatically. In between, when you get the following screen, just close it.

## MCS7840/7820 User Manual for Windows Vista Certified driver



**Note:** Installation of remaining serial ports will take some time. This is the common behavior of Windows Vista, as the Vista OS searches for driver in Windows Update location first and then searches in the location specified by us.

MCS7840/7820 device detection can be confirmed by checking at the Device Manager. Check for “*High-Speed USB MultiSerial Compound Device*” under *Multi-port serial adapters*, and you will find “*High-Speed USB Serial Port (ComX)*” under the category *Ports (COM & LPT)*. Here ‘X’ in ‘ComX’ represents the serial port number. You can see the same in the figure below.

